Wikiprint Book

Title: User Guide for the DEEP system

Subject: DEEP - Public/User_Guide

Version: 40

Date: 11.05.2025 18:34:09

Table of Contents

User Guide for the DEEP system **3**
System overview 3
Access the system 3
How to use certain partitions and nodes 3
Information on software and tools 3
Problems and solutions 3
Reporting Problems 3

User Guide for the DEEP system

System overview

- Hardware details
- Filesystems

Access the system

- Get an account
- Information about the batchsystem

How to use certain partitions and nodes

- DEEP-EST Cluster Module (dp-cn)
- DEEP-ER SDV Cluster
- DEEP-ER SDV KNLs
- Use the FPGA test system?

Information on software and tools

- Available software and Modules environment
- Programming with OmpSs-2
- Usage of TAMPI
- Parallel I/O with SIONlib
- Resiliency:
  - Usage of SCR (Scalable Checkpoint Restart)
  - Using FTI (Fault Tolerance Interface)
  - Usage of OpenCHK
- Intel Advisor XE (Vectorisation analysis)
- Integrate applications in JUBE
- the Benchmark Suite

Problems and solutions

- Known issues and solutions (workarounds)

Reporting Problems

- For general application problems or running jobs please write an email to the support list: sup(at)deep-est.eu
- Problems at DEEP with system management in general or other unspecified issues should be reported by creating a ticket. To do so please send a mail to deeptrac(at)par-tec.com
- Chat: chat.freenode.net, port 6667, Channel #DEEP_User